

FS-1 FireStore Factory Reset

To factory reset the FS-1, hold the SHIFT/ALT button down until it flashes, then press and hold the MODE button until the menu shows. Press the MODE button repeatedly until you see FACTORY RESET, then press the |<< or the >>| button to perform the reset.

Why must I perform the Factory Reset?

The NVRAM is susceptible to power spikes and fluctuations. Even to spikes in the video and audio signal lines caused by incorrect voltages or static electricity discharge (very rare).

If you have to perform a Factory Reset, it is wise to examine the cause. Some do's and don'ts:

- If the unit is plugged into a power strip, never apply or remove power from the unit using the switch on the power strip.
- Never remove power to the unit without first pressing the "Power" key on the keyboard or front panel
- If the power in your area is unstable or your lights dim and grow brighter on occasion, it is wise to invest in a power conditioner or UPS (Uninterruptible Power Supply).