



## TVIEW MICRO

Problem	Possible Causes/Solutions
I believe everything is connected properly, but my TV only shows snow/static.	<p>The TV or VCR is not set up properly. Whatever the TView Micro is connected to, TV or VCR, <u>MUST</u> be set to the proper VIDEO mode. It is usually a button on the remote control for the TV or VCR, or an on-screen menu option. It may be called INPUT, VIDEO, AUX, LINE, etc. Refer to the TV or VCR's documentation for further assistance.</p> <p>The video cable from TView Micro may not be connected to the correct input on the TV or VCR.</p>
The image on the TV is jumping or flipping around.	<p>Set resolution in Display Properties to 640x480, 256 colors, at 60 Hz Refresh Rate (<a href="#">see VGA Adjustment on Tech. Support web page</a>)</p> <p>Make sure the power light on the front of the TView Micro is on, solid green.</p> <p>Set dip switches to 1 down, 2, 3, &amp; 4 up (see page 9 in manual).</p>
I have the image on the TV, but it is not in color.	<p>Reverse the RCA or S-Video cable.</p> <p>Check for bent or broken pins.</p>

	Set dip switches to 1 down, 2, 3, & 4 up (see page 9 in manual).
	Press "Reset" button (on top of the TView Micro) 3 times (see page 8 in manual).
The green power LED does not light.	Check power connections (wall outlet and TView Micro).  Check for +5V DC on the power supply/transformer of the TView Micro.
My laptop's display is fine, but the TV is distorted or blank.	You need to press the function key (Fn) and the laptop's CRT activation key (F1 through F12). Usually the key has a monitor icon on it, ( <a href="#">see VGA Adjustment on Tech. Support web page</a> ).
The edges are overflowing on my TV. How can I fix this?	This is called "Overscan". The TView/PC Micro does not provide a compression feature. Moving the image to the top, left corner of the TV is the best thing to do. Our higher end products provide a single button for compression.
My TV doesn't have an RCA or S-Video input. It only has a coaxial cable input, like for my cable box.	You need to connect the RCA/Composite video cable from the TView Micro to a RF Modulator, (Radio Shack model #15-1244) or VCR.
Can I use my VCR to connect the Micro to my TV?	Yes. Both TV and VCR must be set to Ch. 3. The RCA cable connects from the Micro's composite video output to the VCR's video input. A coaxial cable will connect the VCR to the TV.
I see the image on the TV, but it is blurry and out of focus. How can I fix this?	See "Improve Quality of Image on TV" on our website under <a href="#">Tech. Support</a> .
Can I watch TV on my computer monitor?	No. A scan converter is a "one-way" device, and can only send NTSC/PAL signals to the TV. It cannot send television signals back into the computer.
Will I be able to see the image on my computer and the TV at the same time?	FOCUS Enhancements Video Converters provide a VGA pass-through cable that enables viewing of a VGA monitor and a TV at the same time. However, most laptops will NOT

I can't hear the audio with my scan converter.

allow simultaneous use of the TV and laptop screen with the TView Micro.

The Micro does nothing to control, create, or connect audio. If your TV or VCR has audio inputs, you connect those to your sound card's audio output with an appropriate cable (not included). A stereo mini-jack to dual RCA cable may be purchased from Radio Shack. RS p/n 42-2481 or 42-2475.

[Terms of Use](#) | [Privacy Policy](#) | [Contact Focus](#)

© Copyright 2005 Focus, Inc.  
All rights reserved.